

Plumbing Installation Instructions

Installation instructions for Adjustable Shower Sets

Note During the initial uses the shower arm may exhibit minor leakage at the knuckle joint. This is only temporary. It can take at least 2 days and up to 2 weeks for the fibre washers to absorb enough water to take their final shape and thickness.

Note Our warranty covers any manufacturing defects. Installation of plumbing products must be carried out by qualified personal. Any damage to our product caused by misuse, incorrect installation or installation by unqualified personnel is not covered by our warranty

Soak the Fibre Washers

1. Loosen the top and bottom Thumb Turns without removing them completely.
2. Place the Arm Assembly in water until required for installation. This will soften the washers. The longer they soak the better their initial performance

Install the Wall Bodies

Jumper Valves Only

1. Wind the Tap Handles anticlockwise until the Spindles top out.
2. Remove the Tap Handles from the Spindles.
3. Unwind and remove the Wall Flanges.
4. Flush the lines and remove any impurities or obstructions from the wall bodies.
6. Remove the protective plastic cup, check that the SBA Fibre Washer and the Valve are in place and then insert into wall body. Turn clockwise until seated.
7. Hand Tighten then with a hand tool Nip the SBA tight with no more than 1/4 turn.
8. Pressure test the Wall Assemblies before proceeding.

Ceramic Discs Only

1. Remove the Tap Handles from the Spindles.
2. Unwind and remove the Wall Flanges.
3. Remove the SBA Outer Locking Ring. Be careful not to damage or dislodge any O-rings. Rest components on a soft, clean, dust proof surface.
4. Flush the lines and remove any impurities or obstructions from the wall bodies.
5. Remove the protective plastic cover and while holding the SBA only, insert into wall body. **Do not hold or push the Spindle, this may dislodge the ceramic cartridge.** Turn clockwise until seated.
6. Hand Tighten then with a hand tool Nip ight no more than 1/4 turn.
7. Wind on the SBA Outer Locking Ring and hand tighten
8. With a hand tool Nip the SBA tight with no more than 1/4 turn.
9. Pressure test the Wall Assemblies before proceeding.

Install the Shower Arm

1. After tiling or similar wall finishing, pare off the 1/2" nipple to 20mm from the finished surface.
2. Position the Wall Dome/Flange over the nipple.
3. Tape Nipple with approved thread sealing tape.
4. Using only a hand tool (wrench or spanner) attach and tighten the Arm Knuckle to the nipple.

Do not use the Shower Arm as leverage to position or tighten the wall knuckle. This will result in damage to the arm assembly and will void your warranty.

6. Adjust the Arm Asembly and Shower Head to the desired position.
7. Hand Tighten the Thumb Turn(s).

Do not use a hand tool to tighten the Thumb Turn(s). This will result in damage to the spindles and will void your warranty.

8. Use the Shower normally and regularly hand tighten the Thumb Turn(s).Note. It is not unusual to experience minor joint leakage until the fibre washers are bedded in. Fibre Washers require at least 2 days to absorb sufficient moisture to reach maximum thickness and performance.

If your Installer damages the spindle, a replacement can purchased from your nearest Recollections store.

